

Installation Instructions

K3620S

2007-2017 Jeep 2-1/2" Stainless Dual

Tools needed: standard and metric deep socket set, aerosol lubricant.
(If your vehicle is equipped with a catalytic converter it is unlawful to remove.)
(Check local laws concerning exhaust modifications)



Removal of Original System

We suggest that a trained professional remove and install your exhaust.

- 1) Start under the vehicle, behind the rear axle loosen the clamp holding the muffler to the exhaust.
- 2) Pry the rubber hangers off the muffler.
- 3) remove the muffler.

Installation of New Performance System

(Do not fully tighten any clamps until the complete system is installed and aligned.)

- 1) Attach the new axle back kit to the outlet of the factory exhaust using the band clamp.
- 2) reattach the rubber hangers to the hanger rods.
- 3) check to leaks